

IX.6.2-SYSTEM-EPRSEG SUBROUTINE EPRSEG

Description

Subroutine EPRSEG is the driver routine for printing information about a Segment.

It sets up the appropriate calls to store the Segment information in the ESP arrays and common blocks and then calls the print routine.

Calling Sequence

```
CALL EPRSEG (a,b,c,d,e,f,g,h,i,j,k,l,m,n)
```

Argument List

<u>Argument</u>	<u>Input/ Output</u>	<u>Type</u>	<u>Dimension</u>	<u>Description</u>
a	Input	I*4	1	Record number of the Segment in the Forecast Component file
b	Input	R*4	*	Array P
c	Input	I*4	1	Maximum length of array P
d	Input	R*4	*	Array T
e	Input	I*4	1	Maximum length of array T
f	Input	R*4	*	Array TS
g	Input	I*4	1	Maximum length of array TS
h	Input	R*4	*	Array PESP
i	Input	I*4	1	Maximum length of array PESP
j	Input	R*4	*	Array SPESP
k	Input	I*4	1	Maximum length of array SPESP
l	Input	R*4	*	Array TESP
m	Input	I*4	1	Maximum length of array TSESP
n	Input	I*4	1	Indicator if to punch output: 0 = no punch output 1 = punch output